## **Headlights**

#### ▼ Type A






- The headlights, side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on/off automatically in accordance with ambient light levels.
- The instrument panel, side marker, parking, tail, license plate and daytime running lights turn on.
- The headlights and all lights listed above turn on.
- 4 OFF The daytime running light turn off.

#### ▶ Type B





- The headlights, side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on/off automatically in accordance with ambient light levels.
- The instrument panel, side marker, parking, tail, license plate and daytime running lights turn on.
- The headlights and all lights listed above turn on.
- 4 OFF The daytime running light turn off.

#### ▶ Type C







- 1 O The daytime running lights turn on.
- The headlights, side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on/off automatically in accordance with ambient light levels.
- The instrument panel, side marker, parking, tail, license plate and daytime running lights turn on.
- The headlights and all lights listed above turn on.

To engage the high beams, push the lever forward. To flash the high beams temporarily, pull the lever toward you.

# **Automatic High Beam (If Equipped)**

The Automatic High Beam uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of oncoming and preceding vehicles, etc., and automatically turns high beam on or off as necessary.

#### ▶ Type A



1 Headlight switch in "AUTO" position.



▶ Type B



1 Headlight switch in "AUTO" position.





2 Push the lever away from you.

When all of the following conditions are fulfilled, high beam will be automatically turned on (after approximately 1 second):

- Vehicle speed is above approximately 20 mph (32 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.

# Windshield Wipers and Washer

### ■ Intermittent wiper with interval adjuster (if equipped)

#### ▶ Type A



- 1 O Off
- 2 kintermittent operation
- 3 V Low speed
- 4 ¥ High speed




## ▶ Type B



5 11 2 3 4

- 1 OFF Off
- 2 INT Intermittent operation
- 3 LO Low speed
- 4 HI High speed
- 5 MIST Temporary operation





Intermittent operation: Wiper interval can be adjusted by turning the band.

- 6 Increases the intermittent windshield wiper frequency
- **7** Decreases the intermittent windshield wiper frequency

To spray washer fluid, pull the lever. The wipers will operate automatically.

### ■ Rain-sensing windshield wipers (if equipped)

#### ▶ Type A





- 1 O Off
- 2 AUTO Automatic operation
- 3 V Low speed
- 4 ¥ High speed

### ▶ Type B







2 **AUTO** Automatic operation

3 LO Low speed

4 HI High speed

5 MIST Temporary operation



7 Sensor sensitivity (low)

by turning the band. 6 Sensor sensitivity (high)

Automatic operation: sensitivity can be adjusted



To spray washer fluid, pull the lever. The wipers will operate automatically.

## Rear Window Wiper and Washer

#### ▶ Type A





- 1 O Off
- 2 --- Intermittent window wiper operation
- 3 Normal window wiper operation
- 4 Washer/wiper dual operation
- 5 Washer/wiper dual operation

#### ▶ Type B





- 1 OFF Off
- 2 INT Intermittent window wiper operation
- 3 ON Normal window wiper operation
- 4 Washer/wiper dual operation
- 5 Washer/wiper dual operation